


3. Remove the oil filter (3) with a filter wrench and let the remaining oil drain out.




(3) Oil filter

4. Apply a thin coat of engine oil to the new oil filter rubber seal (4).

Use only the Honda genuine oil filter or a filter of equivalent quality specified for your model. Using the wrong Honda filter or a non-Honda filter which is not of equivalent quality may cause engine damage.

5. Using a special tool and a torque wrench, install the new oil filter and tighten to a torque of:

26 N·m (2.7 kgf·m , 20 lbf·ft)



(4) Oil filter rubber seal