

Display Setting


You can adjust the following settings.

- Clock setting
- (E type only) Changing of speed and mileage unit


If the SET button was not pressed during the adjustment, and no buttons were pressed for about 30 seconds, the display will stop flashing automatically and the adjustment will be cancelled.

1 To set the clock:

- 1 Turn the ignition switch on.
- 2 Press and hold the SEL and SET buttons until the hour digits start flashing.



- 3 Press the SEL button until the desired hour is displayed.
 - ▶ Press and hold to advance the hour fast.



- 4 Press the SET button. The minute digits start flashing.

