

Wheels & Tyres

The tyres are the only point of contact between the ATV and the road. Safety under any riding conditions is dependant upon this small point of contact. Please understand that the tyres will have less grip, as the tread wear decreases.

To safely operate your ATV, your wheels and tyres must be the proper type and size. Also, your tyres must be in good condition with adequate tread, and correctly inflated.

It is important to properly replace parts according to the replacement schedule. We recommend that you leave this work to the experts with the proper equipment and experience.

Wheels that are deformed or damaged must be replaced. Please consult your dealer for replacement.

Tyres age, even if they have not been used or have only been used occasionally.

Cracking of the tread and sidewall rubber, sometimes accompanied by carcass deformation, is an evidence ageing.

Old and aged tyres must be checked by experts to determine the suitability for further use.

⚠ WARNING

Using tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tyre inflation and maintenance.