

If You Have a Flat Tire

Installation

1. Position the wheel.
2. Position the wheel nuts.
3. Tighten the wheel nuts in a crisscross (rather than a circular) pattern to the specified torque:
47 lbf•ft (64 N•m, 6.5 kgf•m)

If a torque wrench was not used for installation, see your Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capability.