


## CYLINDER/PISTON

Measure the connecting rod small end I.D.  
**SERVICE LIMIT: 19.10 mm (0.752 in)**



### PISTON RING INSTALLATION

Clean the piston ring grooves thoroughly and install the piston rings.

#### NOTE

- Avoid piston and piston ring damage during installation.
- Install the piston rings with the marking facing up.
- Do not mix the top and second rings.

Space the piston ring end gaps 120 degrees apart. Do not align the gaps in the oil rings (side rails).

After installation, the rings should be free to rotate in the ring grooves.

