

TROUBLESHOOTING

Wobble or vibration in motorcycle

- Bent rim.
- Loose wheel bearing(s).
- Damaged tire.
- Axle not tightened properly.
- Swing arm pivot bearing worn.
- Bent frame or swing arm.

Soft suspension

- Spring preload adjustment is improper for rider's weight—See Owner's Manual.
- Compression damping adjustment improper—See Owner's Manual.
- Weak shock spring.

Hard suspension

- Spring preload is improper for rider's weight—See the Owner's Manual.
- Compression or rebound damping is misadjusted—See Owner's Manual.
- Bent shock damper rod.
- Swing arm pivot bearings damaged.
- Frame or swing arm bent.

Suspension noise

- Faulty rear damper.
- Loose fasteners.