

Adjusting the Drive Chain Slack

Adjusting the chain requires special tools. Have the drive chain slack adjusted by your dealer.

1. Park your motorcycle on its center stand on a firm, level surface.
2. Stop the engine. Place the transmission in Neutral.
3. Loosen the rear axle nut.

