

## Gauges, Indicators & Displays

---

13	PGM-FI malfunction indicator lamp (MIL) (amber)	Lights when there is any abnormality in the PGM-FI (Programmed Fuel Injection) system. Should also light for a few seconds and then go off when the ignition switch is turned ON and the engine stop switch is at RUN. If the indicator comes on at any other time, reduce speed and take your motorcycle to your dealer as soon as possible. <i>Lamp Check.</i>
14	left turn signal indicator (green)	Flashes when the left turn signal operates.