Tire Puncture ► Removing Wheels

- **7.** Remove the brake caliper bracket, rear wheel and side collars.
 - Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
 - Avoid getting grease, oil, or dirt on the disc or pad surfaces.
 - ➤ Do not push the brake pedal while the wheel is removed.

Installation

- **1.** To install the rear wheel, reverse the removal procedure.
 - ➤ Take care to prevent the brake caliper from scratching the wheel during installation.

NOTICE

When installing a wheel or caliper into original position, carefully fit the brake disc between the pads to avoid scratching them.