


Instruments *(Continued)*

2 Backlight brightness adjustment:

You can adjust the brightness to five levels.

- 1 Press **SEL** button. The brightness is switched.



- 2 Press **SET** button. The backlight is set, and then the display moves to the activating/deactivating of tripmeter A, average fuel mileage and fuel consumption automatic reset mode.