


You can also perform the above settings by using the touch screen.

To disconnect the phone: 

Headset Pairing

This function is disabled while the vehicle is in motion.

- 1 Enable the *Bluetooth*® function on your device.
 - u For details, refer to the instruction manual of your device.
- 2 Select [Bluetooth], and then press the **ENT** switch.

