

7. Pour clean Pro Honda Foam Filter Oil or equivalent (Canada: Honda Foam Filter Oil or equivalent) over the entire surface of the air cleaner. Use both hands to evenly spread the oil into the air cleaner. Gently squeeze out any excess oil. (To keep your hands dry, place the air cleaner in a clean plastic bag before spreading the oil into the air cleaner.)
8. Clean the inside of the air cleaner housing. Install the air cleaner.
9. Install the air cleaner housing cover and screws.
10. Install the left fuel tank shroud ([page 57](#)).