


Checking the Coolant

Check the coolant level in the reserve tank while engine is cold.

1. Place your motorcycle on a firm, level surface.
2. Hold your motorcycle in an upright position.
3. Remove the reserve tank cap/dipstick and wipe it clean.
4. Insert the reserve tank cap/dipstick until it seats, but don't screw it in.
Check that the coolant level is between the upper level and lower level marks in the reserve tank cap/dipstick.
5. Securely install the reserve tank cap/dipstick.

If the coolant level is dropping noticeably or the reserve tank is empty, you likely have a serious leak. Have your motorcycle inspected by your dealer.



Adding Coolant

If the coolant level is below the lower level mark, add the recommended coolant (P. 41) until the level reaches the upper level mark.

Add fluid only from the reserve tank cap/dipstick and do not remove radiator cap.