


Checking & Adding Coolant

Refer to *Safety Precautions* on page 62 .

LEFT CENTER



- (1) reserve tank
- (2) UPPER level mark
- (3) LOWER level mark

1. With the engine at normal operating temperature, check the coolant level in the reserve tank (1). It should be between the UPPER (2) and LOWER (3) level marks.

If the reserve tank is empty, or if coolant loss is excessive, check for leaks and see your dealer for repair.

(cont'd)