


Install the alternator cover.

**CAUTION:**

*The alternator cover (stator) is magnetically attached to the flywheel, be careful during installation.*

Install and tighten the SH bolts to the specified torque.

**TORQUE:** 12 N·m (1.2 kgf·m , 9 lbf·ft)



Connect the alternator 3P white connector.

Install the following:

- Seat cowl (page 2-3)
- Seat (page 2-2)
- Lower cowl (page 2-4)

