

NOTE:

- Release the starter button as soon as the engine starts.
- Do not press the starter button while the engine is running or damage to the engine can result.
- The electric starter will only work when the rear brake pedal is depressed.
- Do not use the electric starter for more than 3—4 seconds at a time. Release the starter button for approximately 10 seconds, then press it again with the throttle slightly open.

NOTA:

- Liberar el botón del arrancador tan pronto como arranque el motor.
- No presionar el botón del arrancador mientras que el motor esté funcionando o el motor podría dañarse.
- El arrancador eléctrico solamente funcionará cuando el pedal del freno esté presionado.
- No utilizar el arrancador eléctrico durante más de 3 ó 4 segundos cada vez. Dejar sin presionar el botón del arrancador durante 10 segundos aproximadamente y luego presionarlo de nuevo con el acelerador ligeramente abierto.