

5. Install the oil filler cap/dipstick.
6. Start the engine and let it idle for a few minutes. Stop the engine. Make sure the oil level is at the upper level mark and there are no oil leaks.

Transmission oil change

Recommended oil:

Use **HONDA 4-STROKE OIL OR EQUIVALENT.**

Use only high detergent, premium quality motoroil certified to meet or exceed US automobile manufacturer's requirements for Service Classification SE or SF.

Recommended oil viscosity:

SAE 10W-30

Capacity:

At disassembly: 0.20 liters At replacement: 0.15 liters

-
5. Instalar el tapón del orificio de llenado de aceite/varilla de comprobación de nivel.
 6. Arrancar el motor y dejarlo al ralentí durante unos pocos minutos. Parar el motor y asegurarse de que el nivel del aceite esté en la marca de nivel superior y de que no haya fugas de aceite.

Cambio del aceite de la transmisión

Aceite recomendado:

Utilizar **ACEITE DE 4 TIEMPOS HONDA O SU EQUIVALENTE.**

Utilizar aceite de motor de primera calidad y muy detergente certificado para hacer frente o exceder los requerimientos de los fabricantes de automóviles de los EE.UU. para la clasificación de serficio SE o SF.

Viscosidad del aceite recomendado

SAE 10W-30

Capacidad:

Al desmontar: 0,20 litros Al cambiar: 0,15 litros