

TURBO MODEL OPERATION

1. An Electric Control Unit (ECU) is provided behind the seat. Do not attempt to disassemble this unit at any time whether or not there is a malfunction. Also keep this part from being splashed directly with water.
2. When cleaning the model, do not expose the Computerized Fuel Injection (CFI) parts to strong jet of water or steam.

FUNCIONAMIENTO DEL TURBOMODELO

1. Detrás del asiento se ha provisto una unidad de control eléctrico (ECU). No tratar nunca de desmontar esta unidad si existiese o no un mal funcionamiento. Evitar también que el agua salpique directamente a esta unidad.
2. Cuando se limpie la motocicleta, no exponer las partes de inyección de combustible por computadora (CFI) a chorros muy fuertes de agua o de vapor.