

STARTING THE ENGINE

NOTE: The electric system is designed to prevent electric starting if the transmission is in gear, unless the clutch is disengaged. However, it is recommended that the transmission be placed in neutral before attempting to start the engine.

WARNING: Exhaust gases contain poisonous carbon monoxide. Never run the engine in a closed garage or confined area.

1. Turn the fuel valve to ON position.
2. Insert the key in the ignition switch and turn to ON. The neutral indicator (green) and oil pressure warning light (red) should go on.
3. Make sure the engine stop switch is in RUN.

ARRANQUE DEL MOTOR

NOTA: El sistema eléctrico está diseñado para que impida el arranque eléctrico cuando la transmisión esté engranada, a menos que el embrague esté embragado. Se recomienda, en todo caso, que coloque la transmisión en el punto muerto antes de ensayar a arrancar el motor.

ATENCION: El gas de escape contiene el monóxido de carbono venenoso. No haga nunca correr el motor en un garaje cerrado o en un lugar confinado.

1. Coloque la palanca del grifo de combustible en posición ON.
2. Inserte la llave en el interruptor del encendido y colóquela en posición ON. La lámpara indicadora de neutro (verde) y la de aviso de presión del aceite (roja) estarán encendidas.
3. Asegúrese de que el interruptor de parada del motor esté colocado en posición RUN.