▌User setting mode

You can change the tachometer segment color from the following color.
Default setting is "BLUE".

Color								
WHITE	RED	AMBER	YELLOW	GREEN	AQUA	BLUE	VIOLET	PINK

To set the color:

▌DCT mode

NC700XD NC750XD

Depending on the dual clutch transmission mode, the tachometer segment color changes as follows.

DCT mode	N	D	S1	S2	S3	MT
Color	WHITE	BLUE	PINK	VIOLET	RED	YELLOW