#### Shifting Gears (Continued) Changing between Neutral and AT MODE/MT MODE

#### Changing from Neutral (N) to AT MODE

Press the D/S side of the N-D switch ((1)). The D mode indicator comes on, "1" is shown in the gear position indicator and first gear is selected.

# Changing from AT or MT MODE to Neutral

Press N on the N-D switch (2).

### Changing between D mode and S mode while in AT MODE

Press the D/S side of the N-D switch. The S or D mode indicator comes on (3, 4).

# Changing between AT MODE and MT MODE

Press the A/M switch (5). The S or D indicator goes out while MT MODE is selected (6).

