

5. Tighten the axle holder nuts to 10–14 N·m (1.0–1.4 kg·m, 7–10 ft·lb) torque.
6. Install the front brake cable and adjust the brake free play.

 **WARNING**

- * *If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly.*