



Suspension

To install the removed parts:

1. Install the subframe. Tighten the three bolts to the specified torque:
 Subframe upper bolt (10):
20 lbf-ft (26 N·m , 2.7 kgf·m)
 Subframe lower side bolts (8) (9):
31 lbf-ft (42 N·m , 4.3 kgf·m)

- If a torque wrench is not used for this installation, see your Honda dealer as soon as possible to verify proper assembly.
2. Connect the electrical connectors by matching the cable colors.
 3. Reinstall the band and the clip.
 4. Tighten the air cleaner connecting tube clamp and the rear brake fluid reservoir stay mount bolt.



5. Install the muffler and tighten the bolts. Be careful not to damage the packing installed inside the muffler clamp.

Tighten to the specified torque:
 Muffler clamp bolt (2) :
14 lbf-ft (20 N·m , 2.0 kgf·m)
 Muffler bolt (lower) (3) :
24 lbf-ft (32 N·m , 3.3 kgf·m)
 Muffler bolt (upper) (4) :
24 lbf-ft (32 N·m , 3.3 kgf·m)

If a torque wrench is not used for installation, see your Honda dealer as soon as possible to verify proper assembly.

6. Reinstall the side cover and seat.

