

Apply grease to the shaft, align the punch marks on the base and shaft and screw in the shaft fully.


Make sure that the punch marks are aligned.

NOTE

- The parking brake shaft has left hand threads.


Screw out the parking brake shaft 1/8 turn.

(1) PUNCH MARKS



Install the boot over the shaft and base, making sure that the boot is seated in the groove in the shaft and base properly.


(1) BOOT



Install a new O-ring in the groove in the base and install the base onto the caliper.

(1) BASE

(2) O-RING



(3) CALIPER

Tighten the bolts.

TORQUE: 20–25 N·m (2.0–2.5 kg·m, 14–18 ft·lb)

(1) BOLTS

