

Engine Oil

6. After the oil has drained, install the drain bolt with new sealing washer and tighten to the specified torque:
18 lbf·ft (24 N·m , 2.4 kgf·m)
7. Pour the recommended oil into the crankcase, approximately:
1.0 US qt (0.9 ℓ)
8. Install the oil fill cap/dipstick securely.
9. Start the engine and let it idle for 3-5 minutes. Stop the engine. Wait 2-3 minutes.
10. With the motorcycle held upright on level ground, check the oil level.
If needed, add oil ([page 64](#)) until it reaches the upper level mark. (Do not overfill.)
11. Check for oil leaks.