Add Engine Oil:

- 12. Fill the crankcase with the recommended oil (page 140), approximately: 3.9 US qt (3.7 $\ensuremath{\$}$)
- 13. Install the oil fill cap/dipstick securely.
- 14. Start the engine and let it idle for 3-5 minutes.
- 15. Stop the engine and wait 2-3 minutes.
- 16. Check that the oil level is at upper level mark on the dipstick (page 142).
- 17. Check that there are no oil leaks.

If a torque wrench is not used for installation, see your dealer as soon as possible to verify proper assembly.