

8. Install the parking brake caliper and tighten the mounting bolts.

Torque: 23 lbf·ft (31 N·m, 3.2 kgf·m)

- Take care to prevent the brake caliper from scratching the wheel during installation.
- Use new mounting bolts when installing the parking brake caliper.

NOTICE

When installing a parking brake caliper into original position, carefully fit the brake disc between the pads to avoid scratching them.

9. Return the muffler to its original position.
10. Install the muffler mounting bolt, washer, collar and mounting nut.
11. Hold the muffler mounting bolt and tighten the mounting nut.

Torque: 20 lbf·ft (27 N·m, 2.8 kgf·m)

12. Tighten the muffler band bolt.

Torque: 13 lbf·ft (17.5 N·m, 1.8 kgf·m)

13. Remove the protective tape or cloth.

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.