

⚠ WARNING

• Contaminants in the system may cause a reduction or loss of braking ability.

CAUTION

• Spilling brake fluid will damage painted, plastic, or rubber parts.

NOTE

• Using wires, hang the front brake master cylinder at least as high as the position it was originally installed at to prevent air from getting into the master cylinder. Do not twist the brake hose.
 • Route the cables and wire harnesses properly.

Requisite Service

• Throttle grip free play adjustment (Section 2 of the Common Service Manual)

Procedure		Q'ty	Remarks
	Removal Order		Installation is in the reverse order of removal.
(1)	Brake switch connector	2	
(2)	Master cylinder holder bolt	2	At installation, tighten the upper bolt first.
(3)	Master cylinder holder	1	• At installation, align the mating surface of the master cylinder and holder with the punch mark on the handlebar. • Install the holder with its "UP" mark facing up.
(4)	Master cylinder assembly	1	
(5)	Handlebar weight	1	
(6)	Right handle switch screw	2	
(7)	Right handle switch housing	1	At installation, align the locating pin the engine stop switch with the hole on the handlebar.
(8)	Throttle cable	2	
(9)	Throttle pipe	1	
(10)	Stop ring	1	
(11)	Right handlebar pinch flange bolt	1	
(12)	Right handlebar	1	At installation, align the stopper on the handlebar with the groove in the top bridge.