

INSTALLATION

Connect the siphon hose to the radiator and install the radiator reserve tank aligning its hook with the engine mounting collar.

Install the removed parts in the reverse order of removal.

NOTE:

At rear fender installation, align the cut-out of the rear fender with the reserve tank filler neck boss.

