

## INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Gear position indicator
- (2) Left turn signal indicator
- (3) Neutral indicator
- (4) PGM-FI malfunction indicator lamp (MIL)
- (5) Speedometer
- (6) High beam indicator
- (7) Right turn signal indicator
- (8) Fuel gauge
- (9) Odometer
- (10) Gear range

