
## NOTE:

- \* In cold weather, leave the choke lever up for several minutes after the engine starts and then gradually push the choke down as the engine warms up.
- \* The Posi-Torque selector lever may be moved while the engine is idling, but it is recommended that the engine be stopped.

## CAUTION:


\* Extended use of the choke may impair piston and cylinder wall lubrication.

\* Do not race the engine during the warm up period. Racing a cold engine wastes fuel and increases engine wear.



(5) Choke lever

(6) Throttle lever



(7) Recoil starter rope