


Gearshift Pedal

The gearshift pedal (1) is near the left footpeg. One full stroke of the gearshift pedal will shift the transmission. The pedal automatically returns to the horizontal position when released. Each stroke of the pedal engages the next gear in sequence.

Depress the pedal to up shift to a higher gear and raise the pedal to downshift.



(1) Gearshift pedal



(1) Shifting sequence