

DESCRIPTION

PARTS LOCATION

- (1) Rear carrier
- (2) Fuel tank cap
- (3) Throttle lever
- (4) Front brake lever
- (5) Starter button
- (6) Headlight switch
- (7) Engine stop switch
- (8) Front carrier
- (9) Oil filler cap
- (10) Footpeg
- (11) Rear brake pedal
- (12) Starter decompression lever

