

Storage Compartment

The storage compartment is at the rear of rear fender. Pull the lever (1) up to open.

WARNING

* *Do not carry the cargo exceed 2.3 kg (5 lbs) in the storage compartment.*




(1) Lever

Shock Absorber

Shock absorber (1) has five adjustment positions for different load or riding conditions.

Position I is for light loads and smooth road conditions. Positions II to V increase spring preload for a stiffer rear suspension, and can be used when the ATC is heavily loaded.



(1) Shock absorber