

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean      R: Replace A: Adjust		EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	VALVE CLEARANCE		I	I	53
	ENGINE OIL		R	R	23
	ENGINE OIL FILTER		R	R	46
*	CARBURETOR IDLE SPEED		I	I	—
	FINAL DRIVE OIL	YEAR: I 2 YEARS: R			60
*	BRAKE SHOE WEAR	YEAR: I (NOTE 3)			56
	BRAKE SYSTEM		I	I	—
*	REVERSE LOCK SYSTEM		I	I	—
*	CLUTCH SYSTEM		I	I	—
*	SUSPENSION			I	—
*	SPARK ARRESTER	(NOTE 1)		C	—
*	NUT, BOLT, FASTENER		I	I	—
**	WHEELS		I	I	—
**	STEERING HEAD BEARING	YEAR: I			—