

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean L: Lubricate R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	SPARK PLUG		I	47
*	VALVE CLEARANCE	I	I	44
*	CARBURETOR	I	I	50
	FUEL LINE	I: (EVERY YEAR)		14
*	FUEL FILTER	C: (EVERY YEAR)		51
	THROTTLE OPERATION	I	I	51
	DRIVE CHAIN	NOTE(2)	I.L	42-43
*	BRAKE SHOES	NOTE (3)	I: (EVERY YEAR)	
	BRAKE SYSTEM		I	40
*	CLUTCH		A	52
*	SPARK ARRESTER		C	53
	ALL NUTS, BOLTS, FASTENERS		I	—
	TIRES		I	19-20
*	STEERING HEAD BEARING		A: (EVERY YEAR)	