

Maintenance Schedule

The following Maintenance Schedule specifies all maintenance required to keep your motorcycle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your Honda dealer meets all of these requirements. Perform the *Pre-ride Inspection* (page 31) at each scheduled maintenance period.

Item	Operation	Frequency				Ref. to page
		1.000 km (625 miles)	3.000 km (1.875 miles)	6.000 km (3.750 miles)	Every ... km (miles)	
Engine oil	Replace (Note 1)	■	■	■	1.500 (937)	18
Engine oil filter screen	Clean	■	■	■	1.500 (937)	—
Engine oil centrifugal filter	Clean			■	6.000 (3.750)	—
Air cleaner	Clean (Note 2)	■	■	■	3.000 (1.875)	49
Spark plug	Clean, adjust or replace		■	■	3.000 (1.875)	56
Valve clearance	Inspect and adjust	■	■	■	3.000 (1.875)	58
Carburetor	Adjust		■	■	3.000 (1.875)	—
	Clean			■	6.000 (3.750)	—
Choke operation	Inspect and adjust	■	■	■	3.000 (1.875)	—
Throttle operation	Inspect and adjust	■	■	■	3.000 (1.875)	—
Fuel line	Inspect	■	■		6.000 (3.750)	—
Fuel strainer	Clean	■	■	■	6.000 (3.750)	51
Clutch system	Inspect and adjust	■	■	■	6.000 (3.750)	14
Headlight system	Adjust	■	■	■	3.000 (1.875)	29