


4. To set the year, press the right control button until the desired year appears.
 - Quick setting – press and hold the right control button until the desired year appears.
5. Press the left control button (5) when the display reaches the desired year. The month display will be flashing.



6. Repeat steps 4 and 5 for the month and day.

7. After finishing the data setting, change over to digital clock setting mode. To set the digital clock. See page 45 .

If the ignition switch is turned off or no operation is performed for 5 seconds during the adjustment mode, the set date will reset.

The present date will reset to "000101" if the battery terminal is disconnected.