

Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine, turn the ignition switch OFF and push the choke knob down to Fully Open. Open the throttle fully and crank the engine several times with the kickstarter. Turn the ignition switch ON and start the engine.

Motor ahogado

Si el motor no arranca después de varios intentos, puede que esté ahogado con demasiado combustible. Para limpiar un motor ahogado, ponga la llave de arranque en OFF y presione el mando del difusor a la posición de completamente abierto.

Abrir completamente el regulador y haga virar varias veces el motor con el pedal de arranque. Girar la llave de arranque a ON y ponga el motor en marcha.