

L

Labels..... 6
Load Limits 17
Loading Guidelines..... 17
Low Oil Pressure Indicator..... 32, 87

M

Maintenance
Fundamentals 46
Importance 42
Safety 42
Schedule 43
Maximum Weight Limit..... 17
Modifications 16

N

Neutral Indicator..... 33

O

Odometer 22, 106

Oil

Engine 50, 64

Overheating 86

P

Parking..... 14
Parts Location 18
Passing light control switch 34
Petrol..... 38, 108
PGM-FI (Programmed Fuel Injection)
malfunction indicator lamp (MIL) 32, 87
Protective Apparel 11

R

Rear Seat..... 58
Rear Suspension 82

Recommended

Coolant 52
Fuel 38
Oil 50

Refuelling 38

Removal

Clips..... 62
Front Seat..... 59
Headlight Assembly 61
Rear Seat..... 58
Side Cover..... 60