

Troubleshooting

Engine Will Not Start (HISS indicator stays on)P. 83

Overheating (High coolant temperature indicator is on).....P. 84

Warning Indicators On or FlashingP. 85

Low Oil Pressure Indicator.....P. 85

PGM-FI (Programmed Fuel Injection)

Malfunction Indicator Lamp (MIL)P. 85

ABS (Anti-lock Brake System) Indicator

(CB500XA only).....P. 86

Other Warning Indication.....P. 87

Fuel Gauge Failure Indication.....P. 87

Tyre Puncture..... P. 88

Electrical Trouble P. 95

Battery Goes Dead P. 95

Burned-out Light Bulb..... P. 95

Blown Fuse P. 100