

Tool kit

The tool kit is stored under the seat. ➔ P. 58

You can perform some roadside repairs, minor adjustments and parts replacement with the tools contained in the kit.

Except U type

- Pin spanner
- 8 × 12 mm Open end wrench
- 10 × 14 mm Open end wrench
- 12 × 14 mm Open end wrench
- Standard/Phillips screwdriver
- Screwdriver handle
- Extension bar
- 5 mm Hex wrench
- Helmet set wire
- Fuse puller

U type only

- Pin spanner
- 8 × 12 mm Open end wrench
- 10 × 14 mm Open end wrench
- 12 × 14 mm Open end wrench
- Standard/Phillips screwdriver
- Screwdriver handle
- Extension bar
- 5 mm Hex wrench
- 22 mm Box end wrench
- 27 mm Box end wrench
- Helmet set wire
- Fuse puller