


## TOOL KIT

---

The tool kit (1) is located under the seat. Minor adjustment and parts replacement can be performed with the tools contained in the kit. Adjustments or repairs which cannot be performed with these tools should be referred to your HONDA dealer.



(1) Tool kit

Listed below are the items included in the tool kit.

- \* 10 x 12mm open end wrench
- \* 14 x 17mm open end wrench
- \* Pliers
- \* No. 2 screw driver
- \* No. 2 cross point screw driver
- \* No. 3 cross point screw driver
- \* Screw driver grip
- \* 22 mm wrench
- \* 24 mm wrench
- \* Handle lever
- \* Spark plug wrench
- \* Pin wrench
- \* 6 mm hex. wrench
- \* Feeler gauge (0.7 mm)
- \* Tool bag