

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages
			x 1,000 km	1	6	12	18	24	30	36	
			x 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
	DRIVE CHAIN		EVERY 1,000 km (600 mi) L, L								61
	DRIVE CHAIN SLIDER				I			I		I	66
	BATTERY			I	I	I	I	I	I		77
	BRAKE FLUID	NOTE (5)		I	I	R	I	I	R		13
	BRAKE PAD WEAR			I	I	I	I	I	I		75
	BRAKE SYSTEM		I		I			I		I	13, 75
*	BRAKE LIGHT SWITCH				I			I		I	—
*	HEADLIGHT AIM				I			I		I	—
	CLUTCH SYSTEM		I	I	I	I	I	I	I	I	17
	SIDE STAND				I			I		I	67
*	SUSPENSION				I			I		I	—
*	NUTS, BOLTS, FASTENERS		I		I			I		I	—
**	WHEELS/TYRES				I			I		I	—
**	STEERING HEAD BEARINGS		I		I			I		I	—