


- ① Brake caliper ③ Stopper bolt lock nut
 ② Brake pads ④ Stopper bolt

5. Brake Pads

Brake pad wear will depend upon the severity of usage, type of driving and condition of the roads. It may be expected that the pads will wear faster on dirty and wet roads. Visually inspect the pads during all regular service intervals to determine the pad wear.

If the pad wears to the red line ①, replace both pads with a new set.

NOTE: Use only HONDA genuine replacement friction pads offered by authorized HONDA dealers. When service is necessary on the brakes, consult your HONDA dealer.



① Red line