

Ref. No.	Description	Function
1	Tripmeter	Shows mileage per trip.
2	Speedometer	Shows riding speed.
3	Odometer	Shows accumulated mileage.
4	Left turn signal indicator (amber)	Flashes when the left turn signal operates.
5	Right turn signal indicator (amber)	Flashes when the right turn signal operates.
6	Tachometer	Shows engine rpm.
7	Tachometer red zone	Never allow the tachometer needle to enter the red zone, even after the engine has been broken in. <b>CAUTION:</b> * The red zone indicates the maximum limits of engine speed and running the engine in the red zone will adversely affect its service life.
8	Gear position liquid crystal display	The motorcycle's gear position is indicated.
9	Fuel Gauge	Shows approximate fuel supply available (see page 13).
10	Tripmeter reset knob	Resets tripmeter to zero (0). Push knob in direction shown.