

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	93	
* CHOKE OPERATION					I		I		I	—	
AIR CLEANER	NOTE (2)						C		C	95	
CRANKCASE BREATHER	NOTE (3)			C	C	C	C	C	C	89	
SPARK PLUGS					I		R		I	90	
* VALVE CLEARANCE							I			—	
ENGINE OIL			R		R		R		R	83	
ENGINE OIL FILTER			R		R		R		R	86	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	94	
RADIATOR COOLANT	NOTE (4)				I		I		R	32	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	—	