

## OPERATION

### PRE-RIDE INSPECTION

For your safety, it is very important to take a few moments before each ride to walk around your motorcycle and check its condition. If you detect any problem; be sure you take care of it, or have it corrected by your Honda dealer.

#### WARNING

Improperly maintaining this motorcycle or failing to correct a problem before riding can cause a crash in which you can be seriously hurt or killed.

Always perform a pre-ride inspection before every ride and correct any problems.

1. Engine oil level - add engine oil if required (page 30). Check for leaks.
2. Fuel level - fill fuel tank when necessary (page 27). Check for leaks.
3. Coolant level - add coolant if required. Check for leaks (pages 25).
4. Front and rear brakes check operation; make sure there is no brake fluid leakage (page 20).
5. Tyres - check condition and pressure (page 31).
6. Drive chain - check condition and slack (page 82).  
Adjust and lubricate if necessary.