

## **MAINTENANCE**

Page	
48	<b>MAINTENANCE</b>
49	Maintenance Schedule
51	Tool Kit
52	Serial Numbers
53	Colour Label
54	Maintenance Precautions
55	Fairing
56	Air Cleaner
57	Crankcase Breather
58	Engine Oil
61	Sparke Plugs
64	Throttle Operation
65	Idle Speed
66	Drive Chain
71	Front and Rear Suspension
72	Side Stand
73	Wheel Removal

Page	
80	Brake Pad Wear
81	Battery
84	Fuse Replacement
86	Stop Switch Adjustment

## **87 CLEANING**

## **88 STORAGE GUIDE**

88	Storage
89	Removal from Storage

## **90 SPECIFICATIONS**

## **94 NOISE CONTROL SYSTEM (AUSTRALIA ONLY)**