

5. Tyres—check condition and pressure (pages 51 – 56 ).
6. Drive chain—check condition and slack (page 104 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions.
8. Lights and horn—check that headlight, tail/brake light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 63 ).
10. Side stand ignition cut-off system—check for proper function (page 112 ).